



Place hands as pictured and release lens near nose piece, then pull out of frame.



1) Insert temple edge of lens into frame at the temple.

2) Stress frame as pictured and rotate lens fully into groove of frame at nose bridge.